TENAX®

Deer Fence Kit Instructions







Step 1:

Lightly tap each post into the ground or if the is hard use a bulb auger to create a pilot hole first. Place each post about 10 feet apart.



Step 2:

Using 5 ties per post, attach the netting to each post and extend the poles as you go around the perimeter of the fence.



Step 3:

Place sod staple every 5 feet at the bottom of the fence.



Step 4:

Create a flap for entry point. Protect your plants.





















